


EZ-200-TM (stock code: 3190-1266)

Type TNC-Male Plug

Non-solder center contact
crimp-on (.213" hex.) outer contact


INSTALLATION INSTRUCTIONS

(Cable Types: LMR-200 and Variants)




STEP 1

1. (A) Trim cable to dimensions shown using a razor knife.
(B) Remove any residual plastic from center conductor.
(C) Deburr center conductor using a fine file or Times DBT-01 tool.



STEP 2

2. (A) Slide weather seal and crimp ring over cable.
(B) Insert cable into connector body until dielectric is fully seated and center conductor is inserted fully into connector center pin.
(C) Trim excess braid flush to shoulder on connector body.



STEP 3

3. (A) Slide crimp ring over braid and crimp as close to body as possible using a .213 hex. die in a Times HX-4 crimp tool or equivalent. Do not crimp rear of crimp sleeve.
(B) Heat shrink weather seal over rear of connector body and down on to cable jacket using hot air gun.