

STRIPPING DIMENSIONS

ASSEMBLY PROCEDURES

- 1. STRIP CABLE AS SHOWN. DO NOT NICK CENTER CONDUCTOR.
- 2. SLIDE CABLE INTO CONNECTOR INSURING CENTER CONDUCTOR MATES WITH CENTER PIN.
- 3. OUTER CONDUCTOR BOTTOMS OUT WITH BODY SHOULDER. SOLDER OUTER CONDUCTOR TO BODY.

*STANDARD TOLERANCES APPLY ONLY TO DIMENSIONS IN INCHES

FAIR

ALLEN, TX 7

TITLE

| | | RVIEW MICROWAVE INC. |
|-----------------------|-----------------|--|
| CAD FILE 022117 SHEET | DWG NO FMCN1198 | NOTES: 1. UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE NOMINAL. 2. ALL SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE AT ANY TIME. 3. DIMENSIONS ARE IN INCHES [mm]. |
| SHEET | | |
| SCALE N/A | CAGE CODE 3FKR5 | |
| SIZE A | | |
| 2233 | | |