



CENTER CONTACT

STRIPPING DIMENSIONS

1. STRIP THE CABLE TO THE DIMENSIONS SHOWN, DO NOT NICK CENTER CONDUCTOR OR METAL COVERING.
2. PUSH THE CENTER CONDUCTOR FULLY INTO THE CONTACT AND SOLDER, REMOVE EXCESS SOLDER.
3. PRESS CONTACT INTO BODY UNTIL IT SEATS.
4. SOLDER THE OUTER CONDUCTOR TO THE BODY STEM.

ASSEMBLY PROCEDURES

FAIRVIEW MICROWAVE INC.

ALLEN, TX 75013 WWW.FAIRVIEWMICROWAVE.COM

NOTES:
1. UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE NOMINAL.
2. ALL SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE AT ANY TIME.
3. DIMENSIONS ARE IN INCHES [mm].

TITLE		DWG NO		CAGE CODE	
		FMCO1045		3FKR5	
CAD FILE	102715	SHEET		SCALE	N/A
				SIZE	A
					2233