





REVISIONS			
REV.	DESCRIPTION	DATE	APPROVED
B	PCR FMCO1053 20220803	09/19/2022	AGANWANI



STRIPPING DIMENSIONS

ASSEMBLY PROCEDURES

1. STRIP THE CABLE TO THE DIMENSIONS SHOWN, DO NOT NICK CENTER CONDUCTOR.
2. INSERT THE CENTER CONDUCTOR INTO THE CONTACT USING THE SPACER.
3. SOLDER THE CONNECTION. REMOVE THE SPACER AND ANY EXCESS SOLDER.
4. INSERT CONTACT INTO THE BODY UNTIL IT SEATS.
5. SOLDER OUTER CONDUCTOR TO THE BODY.

THESE COMMODITIES, TECHNOLOGY OR SOFTWARE WERE EXPORTED FROM THE UNITED STATES IN ACCORDANCE WITH THE EXPORT ADMINISTRATION REGULATIONS, DIVERSION CONTRARY TO U.S. LAW PROHIBITED.



TITLE				
SIZE	CAGE CODE	DRAWN BY	ITEM NO.	REV
A	3FKR5	DMAY	FMCO1053	B
ALL DIMENSIONS SHOWN ARE FOR REFERENCE ONLY.				SCALE
				N/A