



STANDARD TOLERANCES

.X  $\pm 0.2$

.XX  $\pm 0.01$

.XXX  $\pm 0.005$

\*STANDARD TOLERANCES APPLY  
ONLY TO DIMENSIONS IN INCHES

- NOTES:
- HEAT SINK REQUIRED FOR PROPER OPERATION. UNIT IS COOLED BY CONDUCTING TO HEAT SINK.
  - FOR SHUTDOWN PIN USE A MANUAL TOGGLE SWITCH WITH AN OPEN ON ONE END AND SHORT ON THE OTHER END. ONCE THE PIN IS SHORTED OUT, THE AMPLIFIER WILL SHUT DOWN.
  - TTL METHOD: USE A DARLINGTON TRANSISTOR (DARLINGTON PAIR) THAT IS CONNECTED TO A TTL OF YOUR CHOICE WITH AN OPEN AND SHORT PORT. WHEN TTL GOES HIGH (5V), THE UNIT WILL SHUT DOWN.

FAIRVIEW MICROWAVE INC.

ALLEN, TX 75013 WWW.FAIRVIEWMICROWAVE.COM

NOTES:  
1. UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE NOMINAL.  
2. ALL SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE AT ANY TIME.  
3. DIMENSIONS ARE IN INCHES [mm].

TITLE		DWG NO		CAGE CODE	
		FMAM5030		3FKR5	
CAD FILE	021318	SHEET	1 OF 1	SCALE	N/A
				SIZE	A
				7361	